GASTROBACK®

Operating Instructions

DESIGN KETTLE PRO

Art.-No. 42428 Design Kettle Pro

Read all provided instructions before first use!
Model and attachments are subject to change!
For household use only!

Carefully read all provided instructions before you start running the appliance and pay attention to the warnings mentioned in these instructions.

Table of Contents

Knowing the Design Kettle Pro 16

Important safeguards 17

- General safety instructions 17
- Potential risks due to high temperatures 18
- Important safeguards for all electrical appliances 18

Technical specifications 19

Using the Design Kettle Pro 20

- Before first use 20
- Use 20

Safety boil dry protection 20

Care and cleaning 21

- Removable spout filter 21
- Decalcifying the kettle 21

Storage 22

Notes for disposal 22

Information and service 22

Warranty 22

Dear customer!

Congratulations on your new Gastroback Design Kettle Pro. The Kettle is designed for boiling pure drinking water. Powerful 2400 watt heating elements are integrated in the bottom of the stainless steal kettle and therefore protected against damage, making cleaning and decalcifying quite easy. A dual water gauge will help you to measure the required amount of water. For additional safety, your kettle is fitted with an additional thermal cut out. In the event of overheating, the kettle will automatically shut down to prevent further damage.

These instructions for use will inform you about the various functions and features, which make it easy to take pleasure in your new kettle.

We hope that you will enjoy your Design Kettle Pro.

Your Gastroback GmbH

KNOWING THE DESIGN KETTLE PRO

Removable spout filter

Soft opening lid with viewing window

Lid release button

Ergonomic handle

1,7 litre stainless steal water container

Dual water windows

Illuminated power ›ON/OFF‹

Underfloorheating

Multi directional base with cord storage

IMPORTANT SAFEGUARDS

• Carefully read all instructions before operating this appliance and save for further reference.

• Do not attempt to use this appliance for any other than the intended use, described in these instructions. Any other use, especially misuse, can cause severe injuries or damage by electric shock, heat or fire.

• Any operation, repair and technical maintenance of the appliance or any part of it other than described in these instructions may only be performed at an authorised service centre. Please contact your vendor.

General safety instructions

• Only use the appliance for the intended purpose. Any non-appropriate use and misuse can cause damages and heavy personal injuries through voltage and fire. Only operate the appliance as described in these directions. Do not use the appliance in moving vehicles or boats. Only use the appliance indoors.

• Close supervision is necessary when the appliance is used near young children. Do not let young children play with any parts of the appliance.

• The appliance is not intended for use by children or infirm persons without supervision. For storage always keep the entire appliance dry and clean and where young children cannot reach it. Do not place any hard and/or heavy objects on the appliance or any part of it.

• The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Always place the appliance on a stable, level, dry, heat-resistant and easy accessible surface. Do not place the appliance near the edge of the table or counter or on an inclined surface. Ensure, that the power base will not tilt or wobble before placing the kettle on it. Do not place any cloth or tissue beneath or on the appliance to avoid any risk of fire, electric shock and overheating. Always keep the table or counter clean and dry and immediately wipe off spilled liquids.

• During operation keep the appliance in an appropriate distance of at least 20 cm on each side to furniture, walls, boards, curtains and other objects. Do not operate the appliance near any heat-sensitive or moisture-sensitive materials or under boards to avoid damage caused by steam and condensate.

• The kettle is heated electrically. Do not place the appliance and any part of it on or near hot surfaces, (i.e. burner, heater or oven). The appliance and any part of it may never touch hot surfaces.

• Do not leave the power base unattended, when connected to the power supply. Always unplug when the appliance is not in use and before cleaning or moving the power base. Always allow the kettle to cool down before cleaning or refilling.

• Do not use this appliance to boil any other liquids or foodstuffs others than pure drinking water without any additional ingredients.

• Never use abrasive cleaners, cleaning pads or any hard and sharp objects (i.e. metal scouring pads) for cleaning. Clean the kettle and power base with a damp sponge or tissue

and carefully dry the power base and exterior of the kettle after cleaning. Do not handle the appliance or any part of it with violence. The lid is easily opened by pressing the opening button. Do not lift or carry the kettle by the lid. Always use the handle for moving the kettle.

• Do not immerse the kettle base, switch area, power base or power cord in water, or allow moisture to come in contact with these parts. Never place the appliance or any part of it in an automatic dishwasher.

• This appliance is for household use only and not intended for use in moving vehicles or outdoors. Do not operate or store the appliance in humid or wet areas. During operation a little amount of moisture could condensate on the power base. This is no indication for any failure.

Potential risks due to hight temperatures

The exterior of the Design Kettle Pro will get very hot during operation. In addition, beware of steam and hot condensate during operation and even some minutes after switching off the appliance, especially when opening the lid or pouring out water. The kettle is still hot, even some minutes after switching off. Do not touch hot surfaces (exterior of the water container and lid) while the appliance is in use. Always use the handle for moving the kettle. Always use the opening button for opening the lid.

Do not place the kettle on any heat-sensitive objects, while it is hot. Never place any heat-sensitive objects in or on the kettle. Close supervision is important, when moving the kettle immediately after switching off. Take care to hold the kettle level, especially when filled to the maximum level.

• For operation place the appliance on a dry, stable, heat-resistant, water-resistant and level surface (i.e. glass, ceramics, stone). Never place any clothes or other objects on or under the appliance during operation to avoid overheating. Always let the kettle cool down to room temperature before cleaning.

• Always keep your hands, face and arms as well as any clothing and other objects away from the lid and spout during operation to avoid scalds and damage. Beware of steam and hot condensate, when opening the lid. Always keep the lid closed, when operating the kettle. Otherwise power consumption increases significantly and, additionally, the automatic switching off of the heating elements will not work out. Ensure all persons stay in sufficient distance to the appliance during operation.

WARNING! Do not overfill the water container beyond the maximum water level mark 1700/MAX (1.7 litre). Otherwise boiling water could splash from the kettle during operation, causing injuries to persons and damage. Only use clear water without any ingredients. Dry spilled water immediately.

WARNING! Do not open the lid during and after operation. This may result in boiling water splashing from the kettle. Pour all the hot water from the kettle before opening the lid to refill.

Important safeguards for all electrical appliances

Care must be taken when using any electrical appliance. Please adhere to the following precautions:

• Ensure that the voltage rating of your mains power supply corresponds to the voltage requirements of the appliance (230 - 240 V, 50 Hz, AC, rated for 16 A). Always connect the

appliance directly to a separately protected mains power supply wall socket with protective conductor (earth/ground) connected properly. Do not use any extension cord or multi socket outlet. The installation of a residual current safety switch with a maximum rated residual operating current of 30 mA in the supplying electrical circuit is recommended. If in doubt, contact your electrician for further information.

• In various foreign countries, the specifications for power supplies are subject to incompatible norms. Therefore it is possible that power supplies in foreign countries do not meat the requirements for safe operation of the appliance. Thus, before operating the appliance abroad, ensure that safe operation is possible.

• Always handle the power cord with care. The power cord may never be knotted, twisted or squeezed. Do not pull or strain the power cord. Do not let the plug or power cord hang over the edge of the table or counter. Take care that no one will pull the appliance by the power cord, especially when young children are near. Always grasp the plug to disconnect the power cord from the power outlet. Do not touch the plug or power base with wet hands, when the plug is connected to the power supply.

• Before operation completely unwind the power cord, insert the power cord in the gap on the bottom of the power base, and ensure that the power base will not tilt or wobble during operation. Do not place the kettle or power base on the power cord.

• Always switch off the kettle and unplug the power base from the power outlet when not in use and before moving or cleaning the power base. Do not leave the power base unattended while connected to the power supply. Never leave the appliance unattended when in operational mode.

• When the power cord warms up during operation or is likely to be damaged, it must be replaced by an authorised service centre. Do not attempt to repair the power cord!

• Do not immerse the kettle, power base or power cord in water or any other liquid. Do not spill or drip any liquids on the power base, power cord or switch area of the kettle to avoid risk of fire and electric shock. When liquids are spilled on the exterior of the appliance or condensate has built up on the power base, immediately switch off the kettle, unplug the power base and dry the appliance.

TECHNICAL SPECIFICATIONS

Model:	Art.-No. 42428 Design Kettle Pro
Power supply:	230-240V, 50 Hz
Power consumption:	2,200-2,400 W
Length of power cord:	approx. 94 cm
Weight:	approx. 1.3 kg
Dimensions:	approx. 210 x 165 x 230 mm (width x depth x height)
Certification:	CE

USING THE DESIGN KETTLE PRO

Before first use

Remove any promotional material attached to your kettle. It is recommended that before first use, the kettle is filled to the maximum level with cold tap water, boiled and water discarded. Your kettle will only operate when positioned on the power base with the >On/Off< switch in the >On< position. The kettle will automatically switch off once the water has boiled.

Use

To fill the kettle, remove it from the power base and open lid by pressing the lid release button. Fill with the desired amount of water.

NOTE! Always fill the kettle between the minimum (500ml) and maximum (1700ml) marks on the water window. Too little water will result in the kettle switching off before the water has boiled or reached the selected temperature. Filling above the maximum mark (MAX) may result in boiling water splashing from the kettle.

Ensure the lid is locked firmly into place. Position the kettle securely onto the power base. Insert the power plug into a 230/240V power outlet and switch on.

NOTE! This kettle must only be used with the power base supplied. Use caution when pouring water from your kettle, as boiling water will scald. Do not pour the water too quickly.

The kettle will automatically switch off once the water has boiled. Lift the kettle from the power base and pour the water. Take care to hold the kettle level, especially when filled to the maximum level. To re-boil it may be necessary to wait for a few seconds to allow the control to reset. If further heating of the kettle is not required, switch off at the power outlet, unplug the power cord and empty the water from the kettle. Replace the kettle onto the power base and close the lid.

SAFETY BOIL DRY PROTECTION

The kettle is fitted with a safety device, which protects against overheating should the appliance be operated with insufficient water. If this occurs, the kettle will stop heating. Switch off at the power outlet and allow kettle to cool before refilling. Remove the kettle from the power base and add water. Return the kettle to the power base. The safety device will then automatically reset. For additional safety, your kettle is fitted with an additional thermal cut out. In the event of overheating, the kettle will automatically shut down to prevent further damage. Should this occur, take your kettle to an authorized service centre.

WARNING! The appliance is designed for boiling of drinking quality water only. Never use to heat or boil any other liquids or foodstuffs. The lid should always be firmly in place and locked into the closed position before use.

WARNING! Do not press the lid release button on the handle to open the lid during the operation. This may result in boiling water splashing from the kettle. Pour out all the hot water from the kettle before opening the lid to refill.

CARE AND CLEANING

Always unplug the appliance from the power outlet before cleaning.

Removable spout filter

The Design Kettle Pro features a removable mesh filter to remove scale deposits for cleaner water. To remove the scale deposits from the filter, open the lid and slide the filter up and out of the kettle. The filter can be cleaned by running under hot water and rubbing with a cleaning cloth or brush. To replace filter, simply slide the filter down into the slot behind the spout of the kettle and push back into position.

Note! The filter could become damaged with time. Please check regularly and replace if found damaged.

Note! The concealed element in the base of the kettle is made from high quality stainless steel. Any brown stains appearing are the result of mineral deposits and are not rust.

To clean the exterior

The outside of the kettle may be wiped over with a damp cloth and polished with a soft dry cloth.

Note! Do not use chemicals, alkaline cleaning agents, steel wool or abrasive cleaners to clean the inside or outside of the kettle. Use a mild cleaning agent with a soft damp cloth.

Decalcifying the kettle

CAUTION! Never use abrasive cleaners, any chemicals, disinfectants, cleaning pads or any sharp utensils (i.e. metal scouring pads) for cleaning. Handle the kettle and power base without violation. Never place the appliance or any part of it in an automatic dishwasher. Depending on the water hardness in your residential area, mineral deposits build up in the water container, causing decolouration and increasing energy loss. Therefore we recommend to decalcify the water container regularly.

1. Combine ca. 400 to 500 ml vinegar and 800 to 1000 ml water, fill this solution in the kettle and boil. Make sure, the room is well ventilated.

2. Switch off and unplug. Allow to stand overnight.

3. Empty the solution from the kettle. Fill the kettle with clean water to water level mark 1700/MAX, bring to boil and discard the water.

4. Thoroughly rinse the interior of the water container with clear water. After that the kettle will be ready for use.

STORAGE

Store the entire appliance (including the power base and operating instructions) on a clean and dry surface, where it may not tilt or fall and no other objects could fall on it and where it is safe from frost and inadmissible strain (mechanical or electric shock, heat) and where it is out of reach of young children. Do not place any hard or heavy objects on the appliance or any parts of it.

Always switch off the kettle and unplug the power base, when the appliance is not in use. Empty remaining water and place the kettle on the power base to protect the connector pins in the power base from dust. When the appliance is not in use for a long period of time, decalcify the interior of the water container. When required, wind the power cord round the cord storage in the bottom of the power base.

NOTES FOR DISPOSAL

Dispose of the appliance and packaging must be effected in accordance with the corresponding local regulations and requirements for electrical appliances and packaging. Please contact your local disposal company.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available.If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.When replacing old appliances with new once, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.

INFORMATION AND SERVICE

Please check www.gastroback.de for further information. For technical support, please contact Gastroback Customer Care Center by phone: +49 (0)4165/22 25-0 or e-mail: info@gastroback.de.

WARRANTY

We guarantee that all our products are free of defects at the time of purchase. Any demonstrable manufacturing or material defects will be to the exclusion of any further claim and within warranty limits of the law free of charge repaired or substituted. There is no warranty claim of the purchaser if the damage or defect of the appliance is caused by inappropriate treatment, over loading or installation mistakes. The warranty claim expires if there is any technical interference of a third party without an written agreement.

The purchaser has to present the sales slip in assertion-of-claim and has to bear all charges of costs and risk of the transport.